

Radio Setting MODE PSK/DATA

RADIO SETTING	
MODE SSB MODE AM MODE FM MODE PSK / DATA MODE RTTY ENCDEC PSK ENCDEC RTTY	MODE PSK / DATA
	AGC FAST DELAY 160msec
	AGC MID DELAY 500msec
	AGC SLOW DELAY 1500msec
	PSK TONE 1000Hz 1500Hz 2000Hz
	DATA SHIFT (SSB) 1500Hz
	LCUT FREQ 300Hz
	LCUT SLOPE 6dB/oct 18dB/oct
BACK	

RADIO SETTING	
MODE SSB MODE AM MODE FM MODE PSK / DATA MODE RTTY ENCDEC PSK ENCDEC RTTY	MODE PSK / DATA
	LCUT SLOPE 6dB/oct 18dB/oct
	HCUT FREQ 3000Hz
	HCUT SLOPE 6dB/oct 18dB/oct
	DATA OUT SELECT MAIN SUB
	DATA OUT LEVEL 50
	TX BPF SEL 300-2700Hz
	DATA MOD SOURCE MIC REAR
BACK	

RADIO SETTING	
MODE SSB MODE AM MODE FM MODE PSK / DATA MODE RTTY ENCDEC PSK ENCDEC RTTY	MODE PSK / DATA
	DATA OUT SELECT MAIN SUB
	DATA OUT LEVEL 50
	TX BPF SEL 300-2700Hz
	DATA MOD SOURCE MIC REAR
	REAR SELECT DATA USB
	RPORT GAIN 50
	RPTT SELECT DAKY RTS DTR
BACK	